

Quick-Start Software Guide

barox Konfigurationstool blench



barox Kommunikation Oktober 2021 Copyright © 2022 by barox Kommunikation AG Guide Version 1.1

Software version guide as of 1.0.1.0

System requirements:


- x86 (Intel or AMD equivalent) based 4 core CPU (minimum 2 core and 2 threads)
 Computer with Ethernet and TCP/IP interface
- 4 GB RAM
- MS Windows 7 or 10 x64 (administrative or superuser rights required)
- barox 19" and DIN rail switches of the RY series with current firmware (please contact us if you have further questions about compatibility with individual devices)

Intel, AMD, MS Windows (Microsoft) are registered trademarks of their respective companies.




Overview:

- 1 Header Program Control
- 2 Administration area Switch network tree
- 3 Configuration area
- 4 Networkdiscovery and listing switches











Search in discovery area:

By clicking on the range
"Discovery IP-Range" the
the respective Ethernet port the
search for the barox switches
of the specified IP range
is started in the program. Clicking
again ends the search
immediately. The found
devices are listed.



For existing networks, the search can be performed using either HTTP or HTTPs port. By double-clicking on the respective listed switches the current user parameters can be specified for existing devices. When commissioning new devices, the program automatically uses the factory user parameters.








Configuration area:

Double-clicking on the respective switch symbol in the switch explorer opens the register for parameterization and control In the configuration area.

The registers can be arranged horizontally as needed to the arrangement be shifted.






Configuration area:


Besides the basic switch parameters, other actions can be performed.

The "Send Config" button sends
the current configuration
to the switch and causes
Startupconfig to be saved. "Refresh"
triggers a new loading of the parameters.



The "FW Update" function opens the dialog for selecting a firmware file and the "Open" option starts the update. During the update, the update status can be queried using the control panel. "Restart Switch" triggers a restart of the switch.





The button "Add Interface" offers the possibility to create IP interfaces for further VLANs.




Switch Explorer RY-LGSP23-26 × RY-LGSP23-10G SW1 Configuration area: ■ Root Switch Settings ▲]. Test_lab_01 Property Name Configuration Current Set ■ 19" Config Ip Address 192.168.10.1 Model RY-LGSP23-26 ✓ RY-LGSP23-26 System IP Time Settings Port VLAN Config Accounts Use Project Time Settings Use NTP Server Configuration Current Switch Configuration ✓ Set Current Configtool Time System Date 2021-10-22 17:6:12 2021-10-22 17:06:22 Time Zone (GMT + 01:00) Amsterdam, Berlin, Bern, Rome, St. \ 600 Acronym Daylight Saving Time disable disable

Time Settings

The time settings can be set manually or additionally with the option "Set Current Configtool Time" the system time of the tool can be sent to the switch. With the "Use NTP Server" option, NTP servers and their addresses can be configured as timers as an alternative.

System IP Time Settings Port VLAN Config Accounts			
☐ Use Project Time Settings ✓ Use NTP Server			
	Configuration	-	Current Switch Configuration
Time Zone	(GMT + 01:00) Amsterdam, Berlin, I	Bern, F 🕆	600
Acronym			
Daylight Saving Tim	ne disable	V	disable
NTP	Configuration	-	Current Switch Configuration
Automatic (DHCP)			
Interval	50 min	V	60
NTP Server 1	192.168.10.105		192.168.10.105
NITO Common 2			






VLAN Configuration

In the configuration area "Port VLAN Config", the VLAN configuration can be done per port. The Access, Trunk and Hybrid modes with the respective tagging functions are available.



Configuration area:



Accounts

The "Add Account" button opens the dialog to create additional users with corresponding attributes in the switch.



Further functions:

Right click on switch icon in the administration tree:

"Send config to switches" saves all configurations of the switches in the respective folder.

The "Web" function opens the GUI of the respective switch with the standard browser stored in the system.

